

## Siser EasySubli Heat Transfer Vinyl Instructions

<b>Materials</b>	Cotton, Polyester, Poly/Cotton Blends
<b>Cut/Print</b>	Print right reading
<b>Important</b>	Before application or masking, place the printed design on the lower platen of the heat press for 45 seconds to allow the radiating heat from the upper platen to set the ink. Do not close the heat press. Alternatively, you can set the printed design aside and allow it to air-dry for 2 hours.
<b>Temperature</b>	311°F
<b>Time</b>	15 seconds
<b>Pressure</b>	Medium , even pressure
<b>Peel</b>	Peel Warm
<b>Care</b>	Wait 24 hours before first wash, Turn shirt inside out, Machine wash warm with mild detergent, Dry at low setting, No chlorine bleach, Do not dry clean

Note: Because of the wide variety of fabrics and garment manufacturers that exist, we highly recommend that this product be fully tested prior to going into production.